

INSTALLATION INSTRUCTIONS


SCREW PATTERN

SCREWS SHOULD BE PLACED IN THE FLAT OF THE PANEL ADJACENT TO THE RIB. SCREW PATTERN TO BE REPEATED EVERY 2 FT. O.C. FROM EAVE TO RIDGE. USE AT LEAST 70 SCREWS PER 100 SQ. FT.

*NOTE: SCREWS SHOULD BE PLACED ON EACH SIDE OF THE RIB AT THE EAVE.

STORAGE

** EXPOSED FASTENER PANELS SHOULD BE KEPT OFF THE GROUND AND DRY BEFORE USE TO AVOID THE FORMATION OF WHITE RUST. IF PANELS MUST BE STORED FOR A LONG PERIOD OF TIME, THEY MUST BE SEPARATED TO ALLOW AIR FLOW AROUND THE PANEL. PLACE PANEL ON AN INCLINE TO ALLOW ANY MOISTURE TO RUN OFF.



KEEP OFF GROUND !

NAIL PATTERN

EACH NAIL SHOULD BE PLACED IN THE TOP OF THE RIB. MAKE SURE NOT TO OVER DRIVE THE NAILS. NAIL PATTERN SHOULD BE REPEATED EVERY 2' O.C.

SUB STRUCTURE

DRI LOC PANELS CAN BE INSTALLED OVER OPEN PURLINS (24" O.C.) OR ON A SOLID DECKING. WHEN A SOLID DECKING IS USED, A MINIMUM OF 30 LB FELT MUST BE USED AS A MOISTURE BARRIER BETWEEN THE PANEL AND DECK.

ACCESSORIES

- 1 1/2" WOOD SCREW FOR PANEL INSTALLATION
- 3 / 4" METAL SCREW FOR PANEL LAP
- 3/8" MASTIC TAPE ROLL FOR PANEL LAP

CORRECT PANEL LAP

